


Connecting Sockets for burner controls


The **socket burner controls** ensure reliable operation and a high level of robustness while offering ease of connection.

Description	Code	Series
Socket A B	18210130	EMO types GF2, NA2, FV1, G22 series 02, 03 03N, 04, G22/P, G22/E, G22/C,
		EMG types SR3,VE3,VE3.2, M300, AT5, AT5/TR, SD2/TR, BV3, GV2, AT5, BA2, AT5/TR, MF2.4
		R. F. type RE3
Socket D E	18210088	EMG types MF2, SR3/TR, SR3/CM...
Socket MG	18210113	Eurobox types CM381
Socket MOG	18210121	Eurogas types VM44G and VM45G / Eurooil types VM44O and VM45O Eurogas types VM41-VM43 / Euro-Oil series 7-9-10, Digital Euro-Oil
Socket N	18210095	EMO types GF2, NA2, FV1, G22 series 02, 03 03N, 04, G22/P, G22/E, G22/C,
		EMG types SR3,VE3,VE3.2, M300, AT5, AT5/TR, SD2/TR, BV3, GV2, AT5, BA2, AT5/TR, MF2.4
		R. F. type RE3
Socket NE	18210114	EMG types MF2, SR3/TR, SR3/CM...
		Eurogas types VM42
Socket NG	18210094	Eurobox types DSM11, DSM11P, DS11, DS11P, CM191N, CE191, CM391N, CE391, SM191N, SE191, SM192N, SE192, SM152, SE152, MM191N, ME191, MM192N, ME192, SM592N/S, SE592, SE592/S
Socket OG	18210116	Eurobox types MT...
Socket P	18210096	Eurobox types CM191N, CE191, CM391N, CE391, SM191N, SE191, SM192N, SE192, SM152, SE152, MM191N, ME191, MM192N, ME192, SM592N,
Socket NBT	18210124	Eurobox types BT...G / Eurooil types BT...O
Socket MPI	18210120	Eurogas types MPI...

BRAHMA S.p.A.
Via del Pontiere, 31
37045 Legnago (VR) - Italy
Tel. +39 0442 635211 – Fax +39 0442 25683

<http://www.brahma.it>
E-mail: brahma@brahma.it

The socket for burner controls are equipped with core hitches to ensure IP40 protection degree. The following figure show core hitches code 18210200 (fig. a) and code 80536550 (fig. b):



For further information see data sheets of the devices